ROCKWELL™ WINDOW WELLS

GRATE INSTALLATION INSTRUCTIONS

Note: Installation instructions are the same for the cascade, premier, and elite grates.

1. Place the grate on top of the window well.

2. Ensure the straight edge of the grate is flush with the foundation wall.

3. No fasteners or screws are needed for installation.